	JAC JS4 1.5T CVT												
SI	Milages (km) x 1000	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
#	Months	6	12	18	24	30	36	42	48	54	60	66	72
1	Engine oil	R	R	R	R	R	R	R	R	R	R	R	R
2	Engine oil filter	R	R	R	R	R	R	R	R	R	R	R	R
3	Gasket (Drain plug washer)	R	R	R	R	R	R	R	R	R	R	R	R
	Oil drain plug	R	R	R	R	R	R	R	R	R	R	R	R
	Tire position exchange		R		R		R		R		R		R
6	Air filter element	1	R	- 1	R	- 1	R	I	R	- 1	R	I	R
7	A/C Filter	1	R	I	R	I	R	I	R	I	R	I	R
8	Fuel filter				R				R				R
9	Brake fluid	1	I	I	R	I	I	I	R	I	I	I	R
10	Transmission oil						R						R
11	Transmission oil filter						R						R
	Spark plug	1	- 1	- 1	- 1	- 1	R	I	- 1	- 1	- 1	I	R
13	Engine Coolant	1	- 1	- 1	- 1	- 1	I	- 1	R	- 1	- 1	- 1	- 1
14	Fuel pipelines and connections	1	1	ı	1	1	1	1	1	1	1	1	1
15	Cooling pipeline		ı	I	I	I	I	I	I	ı	I	I	- 1
16	Warming pipeline	I	ı	I	ı	ı	I	I	ı	ı	ı	I	- 1
17	Engine noise & vibration	- 1	- 1	_	- 1	I	- 1	I	- 1	1	I	1	
18	Vaccum hose and crankcase ventilation	1	1	I	1	1	ı	1	1	1	1	1	1
19	Intake pipeline sealing	1	ı	I	ı	ı	I	ı	ı	ı	ı	I	- 1
20	Exhausting pipe and lug	ı	ı	ı	ı	ı	I	ı	ı	ı	ı	I	- 1
21	Driving belt (generator, A/C)	1	ı	I	ı	ı	I	ı	ı	ı	ı	I	- 1
22	Engine idling and accelerating function	1	1	ı	1	1	1	1	1	1	1	1	1
23	Tire (pressure & abrasion)	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı
24	Brake pipeline and brake function	1	I	I	1	1	I	ı	1	1	1	1	1
25	Brake disc and brake plate	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı	ı
26	All electrivcal equipment function	1	I	I	1	1	I	ı	1	1	1	1	1
27	Current fault code and historical fault code	1	I	I	1	1	I	1	1	1	1	1	1
28	Fuel injector		ı		ı		ı		ı		ı		ı
29	Ignition Coil		ı		ı		ı		ı				1
	Radiator & Radiator fan		ı		i		i		i		i		1
31	Thermostat		ı		i		i		i		i		- 1
32	Throttle valve		ı		ı		ı		ı		ı		1
33	Steering wheel & regulating mechanism		I		I		I		I		1		_
	Bolts and nuts of chassis and body (Tire/steering/Drive shaft/Suspension)	Т	I	Т	I	Т	I	Т	I	Т	ı	Т	1
35	Four wheel alignment		ı		ı		I		ı		ı		- 1