	JAC J7 1.5T CVT												
Sl	**Milages (km) x 1000**	**10K**	**20K**	**30K**	**40K**	**50K**	**60K**	**70K**	**80K**	**90K**	**100K**	**110K**	**120K**
#	**Months**	**6**	**12**	**18**	**24**	**30**	**36**	**42**	**48**	**54**	**60**	**66**	**72**
1	Engine oil	R	R	R	R	R	R	R	R	R	R	R	R
2	Engine oil filter	R	R	R	R	R	R	R	R	R	R	R	R
3	Gasket (Drain plug washer)	R	R	R	R	R	R	R	R	R	R	R	R
4	Oil drain plug	R	R	R	R	R	R	R	R	R	R	R	R
5	Tire position exchange		R		R		R		R		R		R
6	Air filter element	I	R	I	R	I	R	I	R	I	R	I	R
7	A/C Filter	I	R	I	R	I	R	I	R	I	R	I	R
8	Fuel filter				R				R				R
9	Brake fluid	I	I	I	R	I	I	I	R	I	I	I	R
10	Transmission oil						R						R
11	Transmission oil filter						R						R
12	Spark plug	I	I	I	I	I	R	I	I	I	I	I	R
13	Engine Coolant	I	I	I	I	I	I	I	R	I	I	I	I
14	Fuel pipelines and connections	I	I	I	I	I	I	I	I	I	I	I	I
15	Cooling pipeline	I	I	I	I	I	I	I	I	I	I	I	I
16	Warming pipeline	I	I	I	I	I	I	I	I	I	I	I	I
17	Engine noise & vibration	I	I	I	I	I	I	I	I	I	I	I	I
18	Vaccum hose and crankcase ventilation	I	I	I	I	I	I	I	I	I	I	I	I
19	Intake pipeline sealing	I	I	I	I	I	I	I	I	I	I	I	I
20	Exhausting pipe and lug	I	I	I	I	I	I	I	I	I	I	I	I
21	Driving belt (generator, A/C)	I	I	I	I	I	I	I	I	I	I	I	I
22	Engine idling and accelerating function	I	I	I	I	I	I	I	I	I	I	I	I
23	Tire (pressure & abrasion)	I	I	I	I	I	I	I	I	I	I	I	I
24	Brake pipeline and brake function	I	I	I	I	I	I	I	I	I	I	I	I
25	Brake disc and brake plate	I	I	I	I	I	I	I	I	I	I	I	I
26	All electrivcal equipment function	I	I	I	I	I	I	I	I	I	I	I	I
27	Current fault code and historical fault code	I	I	I	I	I	I	I	I	I	I	I	I
28	Fuel injector		I		I		I		I		I		I
29	Ignition Coil		I		I		I		I		I		I
30	Radiator & Radiator fan		I		I		I		I		I		I
31	Thermostat		I		I		I		I		I		I
32	Throttle valve		I		I		I		I		I		I
33	Steering wheel & regulating mechanism		I		I		I		I		I		I
34	Bolts and nuts of chassis and body (Tire/steering/Drive shaft/Suspension)	T	I	T	I	T	I	T	I	T	I	T	I
35	Four wheel alignment		I		I		I		I		I		I